




VP 063 P ...




VI 063 P ...






Albero uscita / Output shaft




Albero entrata / Input shaft



VP 063 F... / VI 063 F...




FA DX
Standard




FA SX

FB DX
Standard




FB SX

FC DX
Standard




FC SX

FD DX
Standard



FD SX

FE DX
Standard



FE SX